


CUSTOMER GUIDE - HUAWEI / FUSIONSOLAR

RECONNECT YOUR INVERTER TO WI-FI

If monitoring stops updating, this is a Wi-Fi connectivity issue. It does **not** affect generation of your solar system. Five short steps in the FusionSolar app, under three minutes.



§ A · BEFORE YOU START

2 MINUTES

QUICK CHECKLIST

01 PHONE ON HOME WI-FI Connect your phone to the same Wi-Fi network you want the inverter to use.	02 FUSIONSOLAR INSTALLED Download 'FusionSolar' from the App Store or Play Store. Log in with your account.	03 2.4 GHZ NETWORK READY Inverters connect to 2.4 GHz only, not 5 GHz. Know your 2.4 GHz SSID and password before starting.
--	--	--

§ B · STEP-BY-STEP

HUAWEI · FUSIONSOLAR

FIVE STEPS IN THE APP

01 SERVICES OPEN SERVICES TAB In FusionSolar, tap the Services tab on the bottom navigation.	02 WLAN CONFIG TAP WLAN CONFIGURATION Under Services, select WLAN Configuration to open the inverter connection flow.	03 SCAN ICON TAP THE SCAN ICON A QR scanner appears. Tap the blue Scan icon to activate the camera.	04 BOTTOM QR SCAN THE INVERTER QR Scan the bottom QR code on the right of the inverter. On some models the sticker is on the front.	05 2.4 GHZ ENTER WI-FI PASSWORD Select your 2.4 GHz home network and enter the password.
---	--	--	--	--

§ C · APP / INVERTER LOGIN PASSWORD

IF ASKED, THE PASSWORD IS

Fomo1234

Use this when prompted to log in **or** when asked to set a new password during setup.

§ D · IMPORTANT TO REMEMBER

- 01

2.4 GHZ ONLY

Inverters cannot connect to a 5 GHz network. If your router broadcasts both, pick the 2.4 GHz SSID.
- 02

NOT AFFECTING GENERATION

Wi-Fi only affects monitoring. Your system keeps producing energy regardless of connectivity.
- 03

STICKER LOCATION

The QR is usually on the right side of the inverter, near the bottom. Some Huawei models put it on the front face instead.

§ E · TROUBLESHOOTING

IF SOMETHING GOES WRONG

COMMON QUESTIONS

Q1 Scan won't work, what do I do? Ensure adequate lighting on the QR sticker and steady the camera ~15 cm away. If the sticker is faded or damaged, contact FOMO Support. We have your inverter SN on record.	Q2 My home network is not in the list. FusionSolar only shows 2.4 GHz networks. If you don't see your SSID, your router may be on 5 GHz only. Enable the 2.4 GHz band in your router settings.
Q3 It connected, but monitoring is still down. Allow up to 10 minutes after a successful pairing for FusionSolar to sync. If still offline, restart the inverter (turn DC switch off then on after 30 s).	Q4 I changed my Wi-Fi password, do I have to redo this? Yes. Any change to the home Wi-Fi (SSID, password, or router swap) requires re-running these five steps so the inverter can re-authenticate.